Subject Name - Chemistry Name - Shreering Mhatre Division -11 Rollno - 111056 Batch - K3 Experiment No.5 Demonstration of effect of environmental conditions on metal corrosion. Sundaram FOR EDUCATIONAL USE

	* Aim - To Demonstration of effect of environmental conditions on metal corrosion
	* objective- To understand the effect of different pH on corrosion of metal
	* Apparatus: Beaker 100ml, Burette stand etc.
	* chemicals: Hydrochloric acid, Sulfuric acid, Sodium hydroxide etc.
0	
Gundaram	FOR EDUCATIONAL USE

				T
		*	Questions -	
		4		
Q.	1)		A colution is made up to contain O.DIM HCI.	
			what is its pH?	
Α .				
Ans	\rightarrow		$pH = -log(H_30^+) = -log(0.01) = [2]$	
_				
- Co.	2)		Asolution is made up to contain 0.01M NOOH.	
	-		what is its pt?	
Ans	\rightarrow		plt = -log(0.01) = [2], NOW p(0H) = 14-pH	
-				
			P(OH) = 14-2 = 12	
Q ₂	3		A pure metal rod half immersed vertically in	
	9		water starts corrosion at bottom. Justify	
Ans	\rightarrow		when a rod is immersed in water, the region inside	
			the water is exposed to lower oxygen as compared	
			to the region in the upper part which is exposed to	
			air. The region exposed in the air, being protected	
			by oxygen acts as a cathode while the portion	
			inside the water behaves like an anode experiencing	
			electrochemical corrosion due to the difference	
			in electrochemical potential. The difference in	
			cation occurs due to air having more oxygen as	
			compared to water, making the surroundings of both portions of the red very different.	
Sundaram	0		FOR EDUCATIONAL USE	

84)	what is the effect of temperature on the rate of wet corrosion?
Ans >	Since wet corrosion are esentially electrochemical in nature, increased temperature tends to speed up the ions taking part in that reaction. Thus the rate of corrosion increases with increase in temperature due to increase in energy and thus the rate of reactions
Q 5	whether there will be correction in alkaline and neutral medium? Justify.
Ans >	Yes, corrosion does occor in alkaline & neutral medium via absorption of 02 Rusting of Iron happens due to dissolved oxygen in water by oxygen absorption mechanism. At the anodic portion, iron gets dissolved due to the oxidation reaction which takes place and electrons flowtothe cathodic area, combining with oxygen, if present in enough amounts to form ferrous hydroxide which in turn oxidizes into ferric hydroxide. Reactions: - Anode > cathode > Fe > Fe2t + 2c / 22 + H20 + 2e - > 20f Fe2t + 20f (in presence of enoughoz) 7 - > Fe(0H)2 2Fe(0H)2t 1/2 02 + H20 -> 2Fe(0H)3-> Fe203.21+20 (yellow rods)
	Limited supply of 02 -> white Fezou from -> (Black on hydrous)
Sundaram	FOR EDUCATIONAL USE magnite)